

UMTS overview

David Tipper
Associate Professor

Graduate Telecommunications
and Networking Program
University of Pittsburgh
2720 Slides 12

UMTS



- ETSI proposed GSM/NA-TDMA /GPRS evolution under name Universal Mobile Telecom. Services (UMTS)
- Most of 3G licenses in Europe **required** operator to deploy a UMTS system covering $x\%$ of population by a specific date y
 - Germany: *25% of population by 12/03, 50% by 12/05*
 - Norway: *80% of population by 12/04*
 - In most countries operators have asked for and received deployment delay due to dot.com bust and equipment delays
 - Estimate 2.5 Billion euros to deploy a 5000 base station UMTS system
- According to UMTS Forum
 - More than 90 million UMTS users as of 10/06 on operating networks in more than 50 countries
 - Most deployments of UMTS in Europe (~40% of market) and Pacific Rim (~38% market)




UMTS



- UMTS is a complete system architecture
 - As in GSM emphasis on standardized interfaces
 - mix and match equipment from various vendors
 - Simple evolution from GPRS – allows one to *reuse/upgrade* some of the GPRS backhaul equipment
 - Backward compatible handsets and signaling to support intermode and intersystem handoffs
 - Intermode; TDD to FDD, FDD to TDD
 - Intersystem: UMTS to GSM or UMTS to GPRS
 - UMTS supports a variety of user data rates and both packet and circuit switched services
 - System composed of three main subsystems

UMTS System Architecture



- UE (User Equipment) that interfaces with the user
- UTRAN (UMTS Terrestrial Radio Access Network) handles all radio related functionality – WCDMA is radio interface standard here.
- CN (Core Network) is responsible for transport functions such as switching and routing calls and data, tracking users


UMTS System Architecture



- UE
 - ME (Mobile Equipment)
 - is the single or multimode terminal used for radio communication
 - USIM (UMTS Subscriber Identity Module)
 - is a smart card that holds the subscriber identity, subscribed services, authentication and encryption keys
- UTRAN
 - Node B (equivalent to BTS in GSM/GPRS)
 - performs the air interface processing (channel coding, rate adaptation, spreading, synchronization, power control).
 - Can operate a group of antennas/radios
 - RNC (Radio Network Controller) (equivalent to GSM BSC)
 - Responsible for radio resource management and control of the Node Bs.
 - Handoff decisions, congestion control, power control, encryption, admission control, protocol conversion, etc.



UTRAN architecture



UMTS System Architecture




- Core Networks (CN)
 - HLR (*Home Location Register*)
 - database located in the user's home system that stores the master copy of the user's service profile. The HLR also stores the UE location on the level of MSC and SGSN,
 - 3G MSC / VLR
 - Switch and database that serves the UE in its current location for Circuit Switched (CS) services. The MSC function is used to switch the CS transactions, and VLR function holds a copy of the visiting user's service profile, as well as more precise information on the UE's location within the serving system.
 - 3G GMSC (*Gateway MSC*)
 - Switch at the point where UMTS is connected to external CS networks. All incoming and outgoing CS connections go through GMSC.
 - 3G SGSN (*Serving GPRS Support Node*)
 - Similar to that of MSC / VLR but is used for Packet Switched (PS) services. The part of the network that is accessed via the SGSN is often referred to as the PS domain. Upgrade version of serving GPRS support node.
 - 3G GGSN (*Gateway GPRS Support Node*)
 - Functionality is close to that of GMSC but is in the relation to PS services. Upgraded version of gateway GPRS support Node

Core network




- The Core Network (CN) and the Interface I_u are separated into two logical domains:
- Circuit Switched Domain (CSD)
 - Circuit switched service including signaling
 - Resource reservation at connection setup
 - 3G versions of GSM components (MSC, GMSC, VLR, HLR)
 - I_{uCS}
- Packet Switched Domain (PSD)
 - Handles all packet data services
 - 3G versions of GPRS components (SGSN, GGSN)
 - I_{uPS}
- General approach of building on GSM/GPRS infrastructure ,helps to saves \$ and faster deployment

Core network: architecture




GSM → GPRS Evolution



GSM → GPRS → UMTS Evolution



GSM → GPRS → UMTS



Telcom 2720

12



WCDMA



- Wideband Code Division Multiple Access (WCDMA)
 - The air radio interface standard for UMTS
 - Wideband direct sequence spread spectrum
 - Variable orthogonal spreading for multiple access (OVSF)
- Three types of interface :
 - FDD: separate uplink/downlink frequency bands with constant frequency offset between them
 - TDD: uplink/downlink in same band but time-shares transmissions in each direction
 - Dual mode :supports FDD and TDD
- Wide range of data rates due to CDMA with variable spreading, coding and modes
 - Varying user bit rate is mapped to **variable power** and **spreading**
 - Different services can be mixed on a single carrier for a user

Telcom 2720

WCDMA



- 5-MHz Channel (25 GSM channels)
 - Each service provider can deploy multiple 5MHz carriers at same cell site
 - Each 5 MHz shared by multiple subscribers using CDMA
 - Maximum chip rate = 3.84 Mchips/sec
- Standard advantages of CDMA
 - Soft handoff
 - Frequency reuse cluster size of 1,
 - Better quality in multipath environment
 - RAKE receiver
- QPSK modulation

Scrambling and Channelization




- Channelization codes are orthogonal codes
 - Separates transmissions from the same source
 - Uplink: used to separate different physical channels from the same UE – voice and data session
 - Downlink: used to separate transmissions to different physical channels and different UEs
 - UMTS uses orthogonal variable spreading codes
- Scrambling (pseudonoise scrambling)
 - Applied on top of channelization spreading
 - Separates transmissions from different sources
 - Uplink effect: separate mobiles from each other
 - Downlink effect: separate base stations from each other

Physical Layer: Spreading



- Spreading of the low-bandwidth data signal to produce the wideband CDMA signal consists of two steps:
 - Channelization or spreading code to reach channel rate of 3.84 Mchips/s
 - Scrambling – to provide separation of transmissions



Telcom 2720

16

Channelization Spreading



UMTS uses variable spreading and power levels to provide different user data rates. In FDD mode 10 msec frames are used

The number of chips per bits is called the Spreading Factor (SF) and define the data service required for the user:

$$T_{\text{bit}} = \text{SF} \times T_{\text{chip}}$$

For UMTS:

$$\text{Bit Rate} \times \text{SF} = 3.84 \text{ Mchips/s (Chip Rate)}$$

SF can change in every 10 msec frame

Service	Bearer Date Rate (kbps)	SF	Modulation Rate (Mchips/s)
Speech	30	128	3.84
Packet 64 kbps	120	32	3.84
Packet 384 kbps	960	4	3.84

Telcom 2720


17

WCDMA Variable Spreading



The channelization codes are Orthogonal Variable Spreading Factor codes that preserves the orthogonality between a user's different physical channels. The OVSF codes can be defined using a code tree.

In the code tree the channelization codes are uniquely described as $C_{CH,SF,k}$ where SF is the Spreading Factor of the code and k is the code number, $0 \leq k \leq SF - 1$



SF = 1

SF = 2

SF = 4

SF between 4 and 512 on DL
between 4 and 256 on UL


Scrambling and Channelization Codes



	Channelization code	Scrambling code
Usage	Uplink: Separation of physical data and control channels from same terminal	Uplink: Separation of terminals
	Downlink: Separation of downlink connections of different users within one cell	Downlink: Separation of sectors (cells)
Length	4-256 chips (1.0-66.7 μ s) Downlink also 512 chips	Uplink: 10 ms 38400 chips or 66.7 μ s = 256 chips Downlink: 10 ms = 38400 chips
Number of codes	Number of codes under one scrambling code = spreading factor	Uplink: Several millions Downlink: 512
Code family	Orthogonal Variable Spreading Factor (OVSF)	Long: Gold code Short: Extended S(2) family
Spreading	Yes, increases transmission bandwidth	No, it does not affect transmission bandwidth



WCDMA QPSK Modulator




Turbocodes



- Used in 3G cellular (UMTS) standard
- TurboCode: Concatenation of codes with interleaving - followed by an *iterative* algorithm for decoding
- Use soft decisions to make the decoding powerful.
- Instead of counting differences in bit positions, distance probabilities are used.


Concatenated Code System




WCDMA Forward Error Control



- Convolutional Coding: for voice and control info
 - $\frac{1}{2}$ rate and $\frac{1}{3}$ rate codes with constraint length 8
- Block Interleave over 10, 20, 40, or 80 ms
- Turbo Coding for data and some control info
 - Two parallel rate $\frac{1}{3}$ convolutional codes with interleaving – block length 320 – 5120 bits
 - Iterative decoding to improve BER in poor channel environments.



Turboencode Performance




WCDMA Parameters



<i>Channel bandwidth</i>	5.MHz
<i>Downlink RF channel structure</i>	Direct spread spectrum QPSK modulation
<i>Chip rate</i>	3.84 Mcps
<i>Frame length</i>	10ms/20ms (optional TDD mode)
<i>Handover</i>	Softer handover, soft handover and interfrequency handover

UMTS FDD frame structure




UMTS



- Data rate adjusted every 10 msec by variable spreading and power

band rates between 800 Hz and 1.5 kHz. That is, base station equipment measures the power received from each mobile unit as much as 1500 times a second and issues commands to the mobiles at that rate to raise or lower their output power. Many users can be

[1] Unlike second-generation narrowband code-division multiple-access systems, wideband CDMA, or WCDMA, allows network operators to dynamically reassign channel bandwidth (vertical axis) in response to user needs. These bandwidth allocations are updated every 10 ms, as shown. The bandwidth allocations in each of a system's channels can be changed independently of one another.



UMTS



- Protocol Stack

- User Plane

- Radio Link Control (RLC)
 - Presents a reliable channel to higher layers by retransmitting erroneous packets
- Medium Access Control (MAC)
 - Channel access, multiplexing traffic streams, scheduling priority flows
- Physical Layer
 - Measurements, power control algorithms

- Control Plane


- Radio Resource Control (RRC)
 - Connection and QoS management
- Radio Resource Management (RRM)
 - Algorithms for admission control, handovers

UMTS protocol stacks (user plane)



Circuit Switched Domain

Uses same protocols as GSM



RLC Functions




- Segmentation and reassembly
- Concatenation
- Padding
- Transfer of user data
- Error correction
- In-sequence delivery
- Duplicate detection
- Flow control
- Sequence number check (UM)
- Protocol error detection and recovery
- Ciphering
- Suspend/resume function for data transfer


Air Interface/Physical Layer



- Radio interface protocol architecture around the physical layer



MAC Architecture



MAC Functions



- Mapping of logical channels onto transport channels
- Selection of transport format for each transport channel
- Priority handling between data flows of one MS
- Priority handling between MSs by means of dynamic scheduling
- Identification of MSs on common transport channels
- Multiplexing/demultiplexing of higher layer PDUs into/from transport blocks to/from the physical layer
- Traffic volume monitoring
- Dynamic transport channel type switching
- Ciphering
- Access service class selection for RACH transmissions

MAC: Logical Channels




- Control channels:
 - Broadcast control channel (BCCH)
 - Paging control channel (PCCH)
 - Dedicated control channel (DCCH)
 - Common control channel (CCCH)
- Traffic channels:
 - Dedicated traffic channel (DTCH)
 - Common traffic channel (CTCH)

MAC Entities



- **MAC-b** handles the following transport channels:
 - broadcast channel (BCH)
- **MAC-c/sh** handles the following transport channels:
 - paging channel (PCH)
 - forward access channel (FACH)
 - random access channel (RACH)
 - common packet channel (UL CPCH). The CPCH exists only in FDD mode.
 - downlink shared channel (DSCH)
- **MAC-d** handles the following transport channels:
 - dedicated transport channels (DCH)

MAC: Mapping Between Logical Channels and Transport Channels




Physical Channels




- Primary Common Control Physical Channel (PCCPCH)
- Secondary Common Control Physical Channel (SCCPCH)
- Physical Random Access Channel (PRACH)
- Dedicated Physical Data Channel (DPDCH)
- Physical Downlink Shared Channel (PDSCH)
- Physical Common Packet Channel (PCPCH)
- Synchronization Channel (SCH)
- Common Pilot Channel (CPICH)
- Acquisition Indicator Channel (AICH)
- Paging Indication Channel (PICH)
- CPCH Status Indication Channel (CSICH)
- Collision Detection/Channel Assignment Indicator Channel (CD/CA-ICH)


Physical Channels – Physical Random Access Channel (PRACH)



Physical Channels – Dedicated Uplink Physical Channel



Physical Channels – Physical Common Packet Channel (PCPCH)




UTRAN Procedures



- Fast closed-loop power control
- Open-loop power control
- Paging
- Random-access channel procedure
- CPCH operation
- Cell search
- Transmit diversity
- Handover measurements
- Soft Handoff

UMTS Architecture: Control Plane



[2]

RRC: Functions and Signaling Procedures



- Broadcast of information related to the non-access stratum (Core Network)
- Broadcast of information related to the access stratum
- Establishment, maintenance and release of an RRC connection between the UE and UTRAN
- Establishment, reconfiguration and release of Radio Bearers
- Assignment, reconfiguration and release of radio resources for the RRC connection
- RRC connection mobility functions
- Control of requested QoS

RRC: Functions and Signaling Procedures (cont.)



- UE measurement reporting and control of the reporting
- Outer loop power control
- Control of ciphering
- Slow DCA (TDD mode)
- Paging
- Initial cell selection and cell re-selection
- Arbitration of radio resources on uplink DCH
- Timing advance (TDD mode)
- CBS control.

UMTS Diversity



- UMTS – DS- CDMA support multi-path diversity
 - Note can tolerate a wider range of multi-path delay spread than IS-95 due to greater spreading
- UMTS supports macro-diversity.
 - Allows UE to transmit the same signal via 2 or more cells, in order to counteract interference problems.
- When macro-diversity is used, and when 2 cells are belonging to 2 Node Bs, that are belonging to 2 different RNCs, these RNCs have a specific functionality:
 - Serving RNC (SRNC): a role a RNC can take with respect to a specific connection between a UE and UTRAN. There is one SRNC for each UE that has a connection to UTRAN. The SRNC is in charge of the radio connection between the UE and UTRAN.
 - Drift RNC (DRNC): a role a RNC can take with respect to a specific connection between a UE and UTRAN. A RNC, that supports the SRNC with radio resources when the connection between the UTRAN and the UE needs to use cell(s) controlled by this RNC, is referred to a Drift RNC.


Power Control



In order to maximize the cell capacity, it has to equalize the received power per bit of all mobile stations at all times.

Open loop power control

The initial power control is Open Loop. The MS (UE) estimates the power level based on the received level of the pilot from the BTS (Node B). If no response is received the MS waits a defined time and retransmits with a higher power level. The MS continues to do this until it receives a response.




Power Control



Closed loop power control

When communication is established, power is controlled by the Closed Loop Power Control.



Power Control



- The RNC sets the target BLER (Block Error Rate) level for the service.
 - RNC derives SIR (Signal to Interference Ratio) target from BLER, and sends it to the BTS.
- Uplink RNC performs frequent estimations of the received SIR and compares it to a target SIR.
 - If measured SIR is higher than the target SIR,
 - the base station will command the MS to lower the power:
 - If it is too low, it will command the mobile station to increase its power:
 - The measured-command-react cycle is executed a rate of 1500 times per second (1.5 KHz) for each mobile station (Inner Loop).
- The RNC calculates the SIR target once every 10 ms (or more depending on services) and adjusts the SIR target (Outer Loop).
- Downlink, same closed-loop power control technique is used but the motivation is different: it is desirable to provide a marginal amount of additional power to mobile stations at the cell edge, as they suffer increased adjacent cell interference.

QoS Classes/Services



Traffic class	Conversational	Streaming	Interactive	Background
Characteristics	Preserve time relation (variation) between information entities of the stream Conversational pattern (stringent and low delay)	Asymmetric applications More tolerant to jitter than conversational class. Use of buffer to smooth out jitter	Request response pattern Preserve data integrity	Destination is not expecting the data within a certain time Preserve data integrity
Application examples	Voice, video telephony, video games	Streaming multimedia	Web browsing, network games	Background download of e-mail, electronic postcard

Conversational Classes




Speech service

- Speech codec in UMTS employs a Adaptive Multi-rate (AMR) technique. The multi-rate speech coder is a single integrated speech codec with eight source rates: 12.2 (GSM-EFR), 10.2, 7.95, 7.40, 6.70, 5.90, 5.15, 4.75 kbps and 0 kbps.
- The AMR bit rates are controlled by the radio access network and not depend on the speech activity.
- For interoperability with existing cellular networks, some modes are the same as in existing cellular networks:
 - 12.2 kbps = GSM EFR codec
 - 7.4 kbps = North American TDMA speech codec
 - 6.7 kbps = Japanese PDC
- The AMR speech coder is capable of switching its rate every 20 ms speech frame upon command.


Admission Control



- Accepts or rejects requests to establish a radio access bearer
- Located at the RNC
- Estimates the load increase that the establishment of the radio access bearer would cause to the radio network
- Check is applied separately for uplink and downlink directions
- Radio access bearer will be accepted if admission control admits both uplink and downlink
- Example:
Wideband
power-based
admission control



Handover in UMTS



Types of UMTS Handoffs




1. Intra RNC: between Node B's or sector of same Node B's attached to same RNC
2. Inter RNC: between Node B's attached to different RNC's, can be rerouted between RNC's locally if link , or rerouted by 3GMSC/SGSN, if RNC's in same service area
3. Inter 3GMSC/SGSN between Node B's attached to different
4. Inter System Handoff – between Node B and BTS along with a change of mode (WCDMA, GSM), (WCDMA, GPRS)

Note types 1,2, and 3 can be a Soft/Softer or Hard handoff, whereas, type 4 is always a Hard handoff

UMTS Intersystem Handoff




- Hard Handover
 - If the UE is obliged to hand over to a different frequency (on another system like GSM or GPRS, or not), this is known as a hard handover.



UMTS to GSM Handover

UMTS Intersystem Handoff



UMTS to GSM Handover ... continued

Location Management




Three types of location updating

1. Location Area (LA)- zone registration as in GSM, plus can require periodic registration of users
2. Routing Areas (RA) – zone registration as in GPRS for packet based services
3. UTRAN Registration Areas (URA) – zone registration for certain types of services

Location Management (III)

Area Concepts



Telcom 2720

63

UMTS Security




- UMTS Security Functions
 - Main security elements from GSM
 - Authentication of subscribers using challenge/response
 - Subscriber identity confidentiality (TMSI)
 - SIM card (call USIM)
 - Authentication of user to USIM by use of a PIN
 - Radio interface encryption
- UMTS enhancements/new features
 - Mutual authentication to protect against false base stations
 - New encryption/key generation/authentication algorithms with greater security
 - Encryption extended farther back into wired network (prevents eavesdropping on microwave relays)

Telcom 2720

64

UMTS Security Architecture




UMTS Security



- UMTS authenticates and encrypts circuit switched and packet switched connections separately (even from same MS)
- AUC and USIM have 128 bit shared secret data
 - When authentication requested AUC generates a vector of 128 bit integrity keys (IK) using algorithm f4 with a 128 bit random number input RAND
- Authentication challenge is created using algorithm f9 with inputs:
 - Integrity Key
 - Direction of transmission (up or downlink)
 - 32 bit random number: FRESH
 - Hyperframe count (32 bits) – prevents replay attacks
 - Only RAND and FRESH and the correct response are transmitted over the air

UMTS Security




UMTS Security



- After authentication encryption provided using algorithm f8, with inputs
 - 128 bit cipher key CK, Hyperframe count (32 bits), direction, etc.
- CK is created by algorithm f3 using 128 bit random number RAND and 128 bit shared secret data of USIM/AUC
- The encryption algorithms allow for future improvement
- User specifies protocol version (algorithm used) in set up message along with times for length of using IKS
 - Currently Kasumi algorithm or Advanced Encryption Standard are used for f8 and f9
 - May eventually move to using IP level encryption and authentication

UMTS System Architecture



Telcom 2720

The UMTS system architecture

69

HIGH SPEED DOWNLINK PACKET ACCESS (HSDPA)



- HSDPA \approx 3.5G system upgrade of UMTS
- Standardised in *3GPP Release 5*
- Objective is to support *delay-tolerant* services in *low mobility* scenarios with with enhanced *resource efficiency* and *service quality*
 - support for background, interactive and (to some extent) streaming services
 - low mobility
 - enable *downlink* peak rates of 8-10 Mbits/s \gg 3G requirements
 - lower resource consumption per transferred delay-tolerant bit

Telcom 2720

70

HIGH SPEED DOWNLINK PACKET ACCESS




- HSDPA upgrade of UMTS similar to EDGE upgrade of GPRS
 - completely backwards compatible
 - no new spectrum needed
 - reuse existing infrastructure and 5MHz channels
 - primarily software and minor hardware upgrades
 - coexistence of HSDPA- and non-HSDPA-enabled terminals
 - coexistence of HSDPA- and non-HSDPA-enabled NODE-Bs
 - data flows on HS-DSCH moving from non-HSDPA-cell to HSDPA-cell are automatically switched to a supported transport channel, e.g. DCH
 - gradual hot-spot-based network upgrades possible
 - cost-effective

Te

1

HSDPA Architecture




- Upgrade UMTS downlink channels to a *HS* version:
 - *higher-order modulation*: QPSK and 16-QAM
 - *fast link adaptation*: adaptive modulation and coding
 - *fast channel-aware scheduling*: centered at the **node B**
 - *fast hybrid ARQ on downlink*: combines FEC and selective ARQ
 - *reduced TTI of 2 ms*: to facilitate better tracking of channel variations
 - HS channels typically transmits at relatively fixed power

NEW PHYSICAL CHANNELS



- PHYSICAL CHANNELS

- HS-PDSCH downlink SF 16 data only (up to 15 streams to a user)
- HS-SCCH(s) downlink MAC-hs signalling, H-ARQ, etc.
- HS-DPCCH uplink SF 256 CQI, (N)ACK



HSPDA vs. UMTS





Figure 6 - Time multiplexing downlink channel with HSDPA

PHYSICAL LAYER PROCESSING



Physical Layer Processing



ADAPTIVE MODULATION AND CODING




- LINK ADAPTATION: channel-dependent AMC
 - typically more efficient for services that tolerate short-term data rate variations
 - with only power-controlled channels, it is difficult to exploit all resources
 - AMC can exploit resources better, at the cost of transfer rate jitter
 - Fixed spreading factor SF but variable number of streams and bits per channel symbol

MODULATION	SPREADING FACTOR	TURBO CODE RATE	BITS/BLOCK/CODE	DATA RATE (15 CODES)
QPSK	16	1/4	240	1.8 Mbps
	16	1/2	470	3.6 Mbps
	16	3/4	711	5.3 Mbps
16-QAM	16	1/2	950	7.2 Mbps
	16	3/4	1440	10.8 Mbps

PACKET SCHEDULING SCHEMES



- Round robin
 - serve data flows cyclically
- SNR-based scheduling
 - serve data flow with highest CQI
- Proportional fair scheduler
 - serve data flow with highest $R(t)/\tilde{R}(t)$, with $R(t)$ the instantaneous rate and the smoothed (α) assigned rate
- Priority reduction scheduler
 - serve data flow with highest $\alpha^{N(t)}R(t)$, with α the priority reduction parameter, and $N(t)$ the number of times scheduled



HSDPA Upgrades



- Infrastructure
 - NODE-B
 - a new MAC sublayer (MAC-hs) is standardised and needs to be implemented in the NODE-B
 - depending on the legacy NODE-B capabilities, this update may be done via remote software downloads or may possibly require hardware upgrades as well
 - RNC is largely maintains the UMTS Release '99 functionality
 - a software-only upgrade is required, e.g. to enable assignment of data flows to the HS-DSCH (~ channel switching)
 - no substantial impact on the CORE network is expected
 - New Mobile Terminals
 - Support physical interface, higher data rates and H-ARQ
- HSDPA deployments began 2006 in Europe, Canada, etc. Over 100 deployments

VoIP
Rich Call
Gaming




HSUPA



- High Speed Uplink Packet Access
- Similar to HSDPA – advanced coding and modulation techniques with hybrid ARQ to improve data rate on uplink channel in UMTS
- Now called Enhanced Uplink (EUL) (3GPP)
- Data rates from .73Mbps – 5.76Mbps, 11.5Mbps being tested
- Uses new Enhanced versions of Signalling and physical channels
- Focus of UMTS now on IP in the backhaul

3GPP IP Reference Architecture



The 3GPP IP reference architecture – all traffic IP - with QoS Classes

UMTS



- UMTS is most popular 3G technology
 - Upgrade path from GPRS/EDGE – primarily in air interface to WCDMA standard
 - WCDMA – variable power/spreading cdma
 - Provides standard benefits of cdma technology (frequency reuse factor 1, soft handoff, etc.)
 - Still in deployment stage in many places
 - Upgrade path to HSPDA and all IP defined